


Field Guide and Trail Notes



Before you hit the trail

Always be prepared before leaving home for a hike.

Equipment checklist

- AdvenChair itself!
- 2. Towing straps
- 3. Gloves for mules

- 5. Front wheel and forward beam
- 6. Bicycle helmet for the rider
- 7. Optional: Towing Poles and Harness

Tool kit (recommended)

- 1. Hex wrenches: 2.5, 3, 4, 5, 6 mm
- 2. Phillips no. 2 screwdriver
- 3. Tire pressure gauge (for presta stems) (optional)
- 4. Spare inner tube (20" x 2" for front wheel)
- 5. Tubeless tire repair kit

- 6. Open end wrenches: 10, 13, 17 mm and 13/16 in.
- 7. Straight blade screwdriver
- 8. Tire pump for presta stems
- 9. Tube patch kit
- 10. Tire lever

Hiking gear

- 1. Appropriate foot gear
- 2. Extra socks
- 3. Water and water purifier
- 4. Warm clothes
- 5. Flashlight or headlamp
- 6. Knife
- 7. Sunscreen, sunglasses, and hat
- 8. First aid kit
- Emergency Locator Device (optional) (e.g. SPOT, www.findmespot.com)

- 9. Food
- 10. Rain gear
- 11. Map and compass
- 12. Matches and fire starter
- 13. Bug repellent
- 14. Emergency shelter (for example, a space blanket)
- 15. Cell Phone

A day pack can be hung on the back of the seat and any member of the team can carry a backpack.

Table of Contents

Equipment checklist	. i
Tool kit (recommended)	. i
Hiking gear	. i
Table of Contents	. ii
Table of Figures	. ii
Introduction	
Parts of the AdvenChair	
Transporting the AdvenChair	
At the Trailhead	
Prepare the Chair	
Install the forward beam and front wheel	
Adjust the AdvenChair for the Rider	
Setup for Driver and Mules	
Choosing a trail and planning a hike	
Team Members	
Safety	
Trail difficulty levels	
Hit the trail	
Minor Maintenance	
Voice Commands	
Hiking Techniques	
Finding Trails to Hike	
Tell your AdvenChair stories	
Trail Notes	
Ready to Roll Checklist	
AdvenChair COVID-19 Protocols	3/
Table of Figures	
Figure 1. Primary parts of the AdvenChair	
Figure 2: Positioning the footrest and casters.	
Figure 3: Installing the main wheelsInserting the brake rotors into the brake caliper	
Figure 4: Install or remove the main wheelsInserting the hub and axle	4
Figure 5: Installing and removing the forward beam	. 7
Figure 6: Positioning the front wheel to install or remove the forward beam	. 7
Figure 7: Controls for adjusting seat position and angle (dump) of the seat bucket	9
Figure 8: Controls for positioning the seat back, armrest, and handgrips	LO
Figure 9: Controls for adjusting the position and angle of the optional upper footrest.	11
Figure 10: Installing and adjusting optional headrest	
Figure 11: Attaching towing poles to forward beam and to towing harness	
Figure 12: Strap attachment points.	13
Figure 13: Handles for lifting the AdvenChair	
Figure 14: Using straps and the handlebars to cross a steep sidehill	23

"You can't go back and change the beginning, but you can start where you are and make a brand new ending."

-James R. Sherman (adapted)



Introduction

Welcome to the growing community of adventurers who refuse to let mobility challenges stop them from enjoying the outdoors on the trail. This Field Guide is designed to help get you and your AdvenChair to the trailhead, along the trail, and home safely so you can enjoy your whole experience. For information about initial setup of the AdvenChair, please refer to the AdvenChair Owner's Manual at www.advenchair.com/xxx.

Parts of the AdvenChair

The primary parts of the AdvenChair are shown in Figure 1.




Figure 1. Primary parts of the AdvenChair.

Transporting the AdvenChair

- Always make sure the AdvenChair is tied down and secure when it is being transported. If the rider will be riding in the chair follow these additional steps:
 - a. Set the parking brakes by pulling the levers and pushing the locking button.
 - Attach the vehicle-mounted tie-down straps (e.g. QStraints) to the AdvenChair frame.
 - c. Attach the seat belt firmly and securely across the waist and the chest strap firmly and securely across the chest. (The straps may need to fit behind the AdvenChair armrests to ensure a secure fit.)
- 2. **Disassembling the AdvenChair**—Only do what's required for the size of your vehicle. For large vehicles you may be able to remove the front wheel and forward beam and roll the chair in.
 - a. Remove the front wheel and forward beam:
 - i. Lower the casters into wheelchair mode by removing the yellow pin in Figure 2, rotating the casters down, and re-pinning.
 - ii. Rotate the front wheel forward to take pressure off the forward beam, with weight on the casters. (Figure 6.)
 - Loosen both of the forward beam clamps with the ratchet handles.
 (Figure 5.)
 - iv. Unpin the white detent pin (Figure 5.) from the forward beam rear clamp.
 - v. Pull the forward beam straight forward, out of the clamps.
 - b. Footrest: Rotate the entire footrest assembly up towards the seat so it is out of the way. (Figure 2.)
 - Pull the red detent pins from the top of the footrest assembly on both sides
 - ii. Pull the blue detent pins from both sides of the footrest tray.
 - iii. Rotate the footrest assembly up so the tubes are straight up and pin the tubes in place. The red detent pin is reinserted from the bottom to keep the footrest up and out of the way.
 - iv. Pin the footrest tray in place using the blue detent pin.
 - c. Casters: Rotate the casters up so they take up less room.
 - i. Tip the AdvenChair on its back
 - ii. Unpin the yellow detent pins from the top of both casters. (Figure 2.)
 - iii. Rotate the casters up and re-pin them using the holes in the front of the caster assembly.

d. Taking off the main wheels

- i. Tip the chair onto its front and have someone hold it in place.
- ii. Unscrew the axles from each wheel with the 6mm hex wrench and pull the wheels "down" and away from the chair. (Figure 4.)
- iii. Screw the axles back into the AdvenChair frame to prevent loss of the axles and to protect their threads.
- Folding the seat: Place the chair upright and push the seat back forward and down.

The chair is now fully disassembled and ready for transport.




Figure 2: Positioning the footrest and casters.

Casters and footrest are shown in wheelchair mode.

Detent Pins:

The pins and the holes they fit into are color coded for clarity.

Red: Controls position/angle of the entire footrest assembly.

- Holes 1, 2, and 3 allow angles of 22, 38, and 45 degrees from vertical for adjustment for the rider.
- For transport and storage, the footrest assembly can be rotated up so the footrest support tubes are vertical and the footrest tray is next to the seat.
 The red pin is then inserted into hole 3 from the bottom to hold the footrest assembly in place.

Green: Adjusts the height of the footrest.
Blue: Controls the angle of the footrest tray.
Yellow: Controls the angle of the caster assembly.

Arrows show direction of rotation of each part, not the detent pins.

View is looking down on the Main Wheel




Figure 3: Installing the main wheels--Inserting the brake rotors into the brake caliper.




Figure 4: Install or remove the main wheels--Inserting the hub and axle.

3. Setting up a fully disassembled AdvenChair

 Unfold the seat back by pulling the top of the seatback up and back until it is upright.

b. Install the main wheels

- i. Tip the chair onto its front.
- ii. Place each wheel in position with the brake rotor in the brake caliper slot (Figure 3.) and the wheel hubs in their dropouts (Figure 4.).
- Slide the axle through the axle dropouts and the hub; screw the axle tight with a 6mm hex wrench.

c. Lower the casters

- i. Tip the chair on its back.
- ii. Pull the yellow pins from each caster, rotate each caster down and pin them in place. (Figure 2.)

d. Position the footrest (Figure 2.)

- i. Tip the chair upright, on its wheels and casters.
- ii. Unpin the footrest assembly by pulling the red pins and the foot rest by pulling the blue pins.
- iii. Rotate the footrest tube down and pin both sides with the red pins in the desired position. There are three holes, for different angles.
- iv. Position the footrest tray in the desired position and pin both sides with the blue pins.

At the Trailhead

Prepare the Chair

- 1. Tire pressure: The maximum safe tire pressure is 35 psi. The tires roll more easily at that pressure but provide more shock absorbance and bounce less at lower pressures. Heavier riders require higher pressure. The lowest pressure that should be used is 15 psi. We recommend starting at 35 psi and adjusting downward depending on preferences and conditions.
- **2. Brakes**: If the brakes are keeping the wheels from spinning:
 - a. Make sure the brake levers are not locked in the brake position with the button on the brake lever.
 - Make sure the wheel is mounted straight and the brake rotor is inside the brake caliper slot.
 - c. There is an adjustment barrel at the brake lever that can be used to loosen or tighten the brakes.

Install the forward beam and front wheel

- 1. Reverse the front wheel to take the weight off the forward beam.
- Slide the rear, round end of the forward beam into the two round clamp blocks above the standard foot rest. Make sure the ratchet handles on both the clamp blocks are loose and the white detent pin is not inserted through the rear bracket. (Figure 6.)
- 3. Insert the white detent pin through the rear bracket and forward beam. The forward beam must be slid all the way into the front bracket and may need to be rotated so the white detent pin will fit through its hole. The clamps should remain loose at this step. Tighten both clamps with the ratchet handles and turn the front wheel into rolling position. This takes the weight off the caster wheels. (Figure 5. and Figure 6.)
- 4. Raise the casters by pulling the yellow pins from the caster assemblies, rotating the casters up, and re-pinning them. (Figure 2.)




Figure 5: Installing and removing the forward beam.

The detent pin securing the front wheel beam is marked white. Note that the white detent pin goes through both the rear clamp and the hole through the end of the forward beam.




Figure 6: Positioning the front wheel to install or remove the forward beam.

When the front wheel is reversed, the casters take the weight and the front wheel is off the ground. When the front wheel is in rolling position the casters are lifted off the ground, putting the weight on the front wheel.

Adjust the AdvenChair for the Rider

Adjusting the AdvenChair for a rider is best done with the rider in the chair, the front wheel in place, and two people to make the adjustments. These adjustments allow sizing the chair for a rider from child sized to adult sized.

1. Footrest: (Figure 2.)

- **a.** Angle of the footrest assembly: The tube supporting the footrest assembly has three positions: 22, 38, and 45 degrees forward from vertical. Pull the red pin on both sides, choose the angle most comfortable for the rider, and re-pin both sides. Taller riders will need the footrest angled farther forward.
- b. Height of the footrest assembly: The tube supporting the footrest assembly telescopes and can be lengthened or shortened. Pull the green detent pins from the tubes on both sides, raise or lower the footrest assembly to a comfortable height, and re-pin both sides.
- c. Angle of the footrest tray: At the top, back of the footrest tray, there is a yellow detent pin on each side and three holes in the each side of the footrest tray. Pin the footrest tray to a comfortable angle by placing the yellow detent pin through the appropriate hole on both sides.

2. Seat position forward and back: (Figure 7.)

People with longer legs typically need the seat positioned farther back.

- a. To position the seat base forward or back, unclamp the seat position ratchet handles under both sides of the seat.
- **b.** Then slide the seat forward or back to a comfortable position and clamp the ratchet handles.

3. Angle (dump) of the seat base: (Figure 7.)

People with longer legs typically need to recline more.

- degrees in four degree increments. The seat shown is currently level and pinned to the bottom hole.
- b. Loosen the seat angle ratchet handles under the back of the seat on both sides. They should only be loosened one half to one full turn.
- c. On each side of the chair, pull the round spring plunger out and turn it 90 degrees to disengage. If the rider is in the seat, the spring plunger may be tight. In this case lift the blue webbing strap at the top of the seat back to unbind the spring plungers, after which they can be pulled out and disengaged.
- **d.** Adjust the seat to a comfortable angle using the blue web strap on the top of the seat back.
- e. Re-engage the spring plungers by turning them back 90 degrees. Then make minor adjustments to the seat angle by using the blue webbing strap at the top of the seat back to rock the seat up and down gently until the pins click into the desired adjustment holes. This may require fitting one side and then matching the other side.
- f. Tighten the ratchet handles on both sides.




Figure 7: Controls for adjusting seat position and angle (dump) of the seat bucket.

Note that there are five seat angle adjustment holes. Two are shown while the other three are hidden.

- 4. Angle of the seat back: The angle between the seat bucket and the seat back is adjusted by lengthening or shortening the side strap which runs diagonally from the seat back to the seat bucket. The buckle on the side strap has two adjustments: one to loosen the side strap and tilt the seat back further back and the second, a ratchet mechanism, to tighten the side strap and raise the seat back to a more upright position. (Figure 8.)
 - **a.** To tilt the seatback further back, lengthen the side strap by pulling out on the gray portion of the buckle and sliding the strap through the buckle.
 - **b.** To raise the seat back to a more upright position, pull the black lever portion of the lever as many times as necessary get the right position.
 - **c.** To get the seat back adjusted evenly, adjust one side and then count the ribs on the side strap that extend past a fixed reference point. Adjust the other side strap to the same length.
- 5. Height of the armrests: (Figure 8.)
 - a. Pull and hold the spring plunger to disengage it
 - **b.** Raise or lower the armrest
 - c. Release the spring plunger to re-engage it into one of the adjustment holes (These holes are not visible in the picture.) There are 5 holes, each ½ inch apart.
- 6. Position of the handgrips: For each handgrip, loosen the ratchet handle just below the armrest and position the handgrip to a comfortable position. The distance between the front end of the armrest and the handgrip and the angle of the handgrip can both be adjusted. Tighten the ratchet handle to clamp the handgrip in place. This is best done with the rider in the chair to ensure the position is comfortable. (Figure 8.) Point the handgrips down for rider loading and unloading.




Figure 8: Controls for positioning the seat back, armrest, and handgrips.

- 7. Adjust the chest strap: Bring both sides of the chest strap around the rider, buckle them together and tighten them by pulling the rings to a comfortable position. Additional length adjustment can be made where the chest straps attach to the seatback. (The chest strap is not shown.)
- 8. Adjust the seatbelt: Bring both sides of the seatbelt across the rider's lap, buckle them, and pull them tight. The tighter the seatbelt, the less the rider will slide forward, but don't make the rider uncomfortable. Additional length adjustment can be made where the seat belt attaches to the seat bucket under the seat cushion. (The seatbelt is not shown.)
- **9.** Adjust the upper footrest (optional component): (Figure 9.)
 - **a. Upper footrest position:** Loosen the ratchet handles on both sides of the front of the upper footrest assembly, slide the upper footrest forward or back to the desired position and clamp it in place with the two ratchet handles.
 - b. Upper footrest angle: Loosen the ratchet handles just below the center of the upper footrest on both sides; pull the pins just in front of those ratchet handles; rotate the upper footrest to an angle comfortable for the rider; insert the pins; and tighten the ratchet handles. There is no button to push to release these pins.
- **10. Strap the rider's feet into the footrest being used:** Buckle the footrest straps together over the rider's feet and pull snug. (The footrest straps are on both the standard footrest and the optional upper footrest and are not shown.)




Figure 9: Controls for adjusting the position and angle of the optional upper footrest.

11. Installation and Adjustment of the Headrest (optional component) (Figure 10.)

- a. The bracket can be lowered 3" by removing the four screws with a 5mm hex key and reattaching the bracket to the four holes below the current bracket position. This will position the headrest for a short person.
- b. Install the headrest: Slide the stem of the headrest support into the headrest bracket and tighten the clamp. The height is adjusted by how far the stem is inserted into the bracket. The bottom of the stem must be in far enough for the clamp to engage with the stem.
- c. Adjust the angle of the headrest: There are two swivel joints on the headrest support. Loosen both of them with a 5mm hex wrench just enough so they can be moved. Adjust the height and angle of the headrest, and tighten the swivel joints.




Figure 10: Installing and adjusting optional headrest.

Setup for Driver and Mules

1. Handle bar adjustment: To raise or lower the handle bar, pull the detent pins on both the steering tubes directly below the handlebars and slide the handle bar up or down. Re-pin at the desired height.

2. Set up for the Lead Mule

- For easy and moderate level trails, attach a towing strap to the front of the forward beam. (Figure 12.)
- **b.** For more difficult trails, especially those involving significant uphill sections, install the towing poles (optional component) (Figure 11.)
 - Screw the poles together—each arm has two sections. The arms are connected by a swivel fitting.
 - ii. To attach the poles to the side of the harness, put the eye bolt at the end of the pole over the webbing loop at the widest point of your hip and slide the carabiner through the webbing loop to secure the poles and minimize slop.
 - iii. Pull the detent pin on the top of the forward beam, insert the towing pole swivel fitting, and insert the pin, attaching the towing poles to the top of the forward beam.
 - iv. Buckle the lead mule into the towing harness.




Figure 11: Attaching towing poles to forward beam and to towing harness.

3. Attaching straps for additional Mules:

Attach the towing straps only when needed on steep uphill or downhill sections of the trail or when the trail crosses a steep sidehill. A carabiner should be attached to the end of each strap and then clipped to one of the attachments on the AdvenChair frame. There are four attachment points on each side of the AdvenChair and if the towing poles are not being used, at the front of the forward beam. (Figure 12.)




Figure 12: Strap attachment points.

There are four attachment points on each side, one at the front of the forward beam, and one on the back of the seat.

4. Lifting handles for Side Mules: Side mules can lift the AdvenChair by the caster legs, the frame next to the main wheels, or the frame where it loops over the main wheels. (Figure 13.) The forward beam should not be used for lifting the AdvenChair but can be used to tilt the chair back on its main wheels (a wheelie).




Figure 13: Handles for lifting the AdvenChair.

There are three handles on each side.

Choosing a trail and planning a hike

Team Members

AdvenChair hiking is a team sport. Everyone has a job and all jobs are important. It's best to switch jobs regularly to make sure everyone understands the team effort and to share the physical and mental effort. Team configuration will vary depending on the terrain and trail conditions.

- RIDER: Sits in the seat and, depending on interest, helps direct the expedition or participates on the ride.
- DRIVER: Pushes the chair, issues commands to start and stop, does most of the steering and braking, and is the primary director of tactics to get around and through obstacles.
- 3. MULE: The mules, a term of endearment for our friends and not to be confused with the Clint Eastwood mules, have a variety of roles and can move from one role to another as needed. The major roles include:
 - a. Lead Mule: Pulls the chair with the towing poles, especially on uphill sections; warns the rest of the team about upcoming obstacles; and helps with steering and braking to a limited extent. On downhill sections, the lead mule may use a towing strap to lift the front wheel over obstacles rather than pulling the

chair with the poles. The lead mule usually acts as the chief scout and directs the speed and decides when to stop progress for discussion of upcoming trail conditions.

 Front Mule: On steep uphill sections, one to four front mules may assist the lead mule pull the chair up the hill with towing straps. Mules are reputed to be more patient, hardy and long-lived than horses and are described as less obstinate and more intelligent than donkeys.

--Wikipedia

- c. **Rear Mule**: On steep downhill sections, one or two rear mules stand behind the driver holding straps attached to the back of the AdvenChair. They exert a backwards force on the chair to help with braking and steering.
- d. Side Mule:
 - On sections of trail across side slopes, side mules can be deployed with towing straps on the uphill side of the chair to keep the chair from rolling over.
 - ii. On rough sections of the trail, side mules lift the chair up and over obstacles (e.g. roots, rocks, logs, or stairs and waterbars). This is most common on uphill trails, but may also be needed on rough flat or downhill trails or on side-sloped trails.

Safety

AdvenChair hiking is about the journey. As with any outdoor activity, continually evaluate the weather and the terrain and be ready to change plans or return home early if conditions are not safe. Safety issues specific to AdvenChair hiking include:

- Communicate. The lead mule has the best view of what's coming and should let
 the driver and other team members know what's ahead. Often the driver can't see
 the trail directly in front of the chair and needs advice about how to straddle or
 steer around obstacles. On rough trails, the team needs to coordinate how to get
 through difficult sections. In these situations, casual conversation, usually
 encouraged, should stop and the team should focus on the obstacle, safety, and
 problem solving.
- Don't be in a hurry. If the trail gets rough, slow down and adjust. Don't barrel through difficult sections to show how competent you and the equipment are.
- 3. Downhill hiking.
 - On a rough trail, downhill hiking is often the most difficult for getting around or over obstacles. Slow down and configure the team for the situation.
 - b. On downhill sections, if using a towing strap, the lead mule must stay aware of the front wheel. In this situation, the lead mule should stay ahead and to the side, out of reach of the front wheel. The driver should pay attention to the location of the lead mule and use the brakes as necessary.
 - c. Keep gravity in mind. Use it, but keep it under control.
 - d. On steep downhills, deploy rear mules to act as a backup to the driver in case the driver loses contact with the brakes.
- 4. Side Mules. Side mules risk trips and falls when they are off the trail. Deploy side mules only when the chair needs to be lifted over obstacles or on steep side hills when straps are needed to keep the chair from tipping sideways. Turning ankles and knees is possible—take good care. Side mules should wear pants or leggings to protect legs from scratches. Side mules on the downhill side often have poor footing and are most at risk. Use mules in the downhill position only when absolutely needed. CAUTION: Side mules should be experienced and in good physical condition.
- 5. Side sloping trails. When the trail is sloped across the direction of travel, the chair could tip or slide to the side. Side mules need to be deployed, carefully, in this situation. If the side slope is steep and the footing above and below the trail is unstable, consider how much of this condition the team can deal with and consider turning around if the team is not comfortable proceeding.
- 6. **Uphill Hiking.** When the lead mule and front mules are both deployed, they sometimes get in each other's way causing tripping and falling hazards. Make sure they are deployed so as not to interfere with each other.
- 7. **Extra person to go for help if necessary.** If the hike extends out of easy reach of help, make sure the team includes at least one person who can stay with the rider and chair and one person who can go for help if needed.

8. 9.	Have a contact at home: Always make sure someone staying at home knows about your plans and can notify emergency help if the team doesn't return when expected. AdvenChair hiking is a team sport. Take care of each other!
	The second second special second seco

Trail difficulty levels

The AdvenChair Trail Difficulty Rating System is modeled after the <u>City of Phoenix Trail</u> <u>Rating System</u> but adjusted for the special requirements of wheelchairs.

Table 1: AdvenChair Trail Difficulty Rating System

Easiest	Surface: Accessible paved or hard footing Steepness: Generally flat with only short sections of gentle uphill or downhill Obstacles: None Trail Width: Greater than 48" with no narrow sections Suggested Minimum Team Size: 2; rider and driver
Easy	Surface: Almost all firm footing with short sections of uneven material Steepness: Generally flat with some sections of easy uphill or downhill Obstacles: 2" or less: Rocks, ruts, or roots. There may be curbs or short sections of 2 to 3 stairs. Trail Width: Greater than 36" with no narrow sections Suggested Minimum Team Size: 3; rider, driver, lead mule
Moderate	Surface: Mostly firm footing with long sections of uneven material Steepness: Includes long sections of moderate uphill or downhill Obstacles: 8" or less: Rocks, ruts, logs, or roots. May include short sections of constructed stairs. Trail Width: Generally greater than 36" with short narrow sections. No or very minor side-slopes. Suggested Minimum Team Size: 4; rider, driver, lead mule, extra mule
Moderate/ Difficult	Surface: Mix of firm footing and loose, uneven material Steepness: Includes long sections of moderate uphill or downhill and short steep sections Obstacles: Many obstacles of 8" or less and occasional obstacles of 12" or less: rocks, ruts, logs, or roots. May include short sections of stairs or uneven steps constructed of logs or rocks. Trail Width: Generally greater than 32" with narrow sections. May include some gentle side-slopes. Suggested Minimum Team Size: 5; rider, driver, lead mule, 2 extra mules

Difficult

Surface: Substantial amount of loose, unstable material and uneven footing

Steepness: Includes long sections of steep uphill or

downhill

Obstacles: Many obstacles of 12" or less: Rocks, ruts, logs, and roots, and with sudden drops or rises in the

trail.

Trail Width: Generally greater than 32" with long narrow sections. Side slopes are common but not

extreme

Scouting: These trails should be scouted before attempting to travel on them with an AdvenChair to ensure they are passable safely with the available team. Suggested Minimum Team Size: 7; rider, driver, lead

mule, 4 extra mules

Extremely Difficult



Surface: Substantial amount of loose, unstable material and uneven footing

Steepness: Includes long sections of steep uphill with some very steep sections.

Obstacles: Many obstacles of 12" or less and some of 18": Rocks, ruts, roots, and with sudden drops or rises in the trail. Some sections of the trail may feel like natural stairs.

Trail Width: Trail can be quite narrow with steep sidehill sections. The rider may have to be carried through some narrow sections.

Scouting: These trails should be scouted before attempting to travel on them with an AdvenChair to ensure they are passable safely with the available team. Suggested Minimum Team Size: 7+; rider, driver, lead mule, 5 or more extra mules



Impossible

Some hiking trails are simply not accessible with any wheelchair. Characteristics that make trails not accessible include: Very narrow; very steep; side slopes that would cause the AdvenChair to tip or slide sideways with unstable footing above and below the trail; large and common obstacles > 18" which can't be navigated around. These trails are extremely unsafe for the entire team and should not be attempted or, if encountered, should cause the team to turn around.

Hit the trail

Minor Maintenance

- Tires
 - a. Main Wheels: The main wheels can be used in an emergency with no tire pressure because the CushCore tire inserts provide enough protection for the rims to roll the AdvenChair with no tire pressure if needed.
 - b. Front Wheel: The front wheel has a standard tire with tube. If it is punctured, it should be repaired by replacing the tube or patching the hole in the tube and re-inflating the tire.
- Brakes: If the brakes rub, make sure the wheel is on straight and adjust the calipers by turning the adjustment barrels on the brake cables at the brake levers. If this doesn't correct the issue, a bike mechanic can trouble-shoot other brake issues.

Voice Commands

Communication between team members is critical. When the going gets tough, clear, incisive commands, usually from the driver, are essential. Other team members, especially the lead mule, need to contribute as needed.

- Start the chair forward: Onward!
- Stop the chair: Stop!
- 3. Back up a bit: Back!
- 4. Stop talking and pay attention: **Focus!**
- 5. Trail obstacles: Rock, Root, Log, Whatever...
 - a. **<Call out the obstacle> right!** (e. g. Rock Right!)
 - b. <Call out the obstacle> left! (e. g. Log Left!)
 - c. An obstacle in the center of the trail: Straddle <Call out the obstacle>!
 (e.g. Straddle Rock!)
- 6. Wheelie! (driver tilts the chair back to lift the front wheel and footrest)
- 7. Develop more voice commands if your group finds them useful.

Hiking Techniques

When encountering new or difficult situations, stop and discuss exactly what everyone will be doing. When the team has learned these techniques, they can often be performed without stopping the chair although discussion is always needed to adjust for conditions. Different teams prefer different techniques and develop new techniques. Keep improvising!

1. Stopping and slowing:

- a. Brakes: The most effective stopping or slowing technique is for the driver to squeeze the brake levers as needed. Lock the brakes with the buttons on the brake lever during any stops.
- b. Poles: If using towing poles, the lead mule can slow the chair by pushing back against the poles. Use care with this technique—if the chair is going too fast or not directly behind the mule, the chair could continue past the mule, pulling the mule around with the poles as the chair passes. Avoid the jackknife! The driver and the lead mule need to be coordinated so the lead mule doesn't get pushed out of the way.
- c. Rear straps: If rear mules are deployed, they can help slow or stop the chair by pulling back on the rear straps.

2. Steering

- Handlebars: The primary steering is done by the driver pushing the handle bars in the direction of travel.
- b. Brakes: The driver can steer with the brakes by squeezing the brake lever on the side towards which the chair should turn. This is most useful while traveling downhill when slowing forward momentum won't put a drag on the lead mule. This steering technique is similar to that used by heavy equipment like tractors or tanks.
- c. Poles and front straps: The lead and front mules can help with steering by pulling the front of the chair around corners with the poles or straps. This is most useful on wide, gentle turns or to direct the front wheel to one side of an obstacle in the trail.
- d. Rear straps: If rear straps are being used, the rear mules can help with the turn. The rear mule on the inside of the turn can hold the strap taut while the other can give the strap some slack. The chair will pivot on the taut strap. This technique is most useful on steep downhill trails. A single rear mule can employ a similar method with a strap in each hand: pull on the side towards which you're turning.

3. Sharp corners:

- a. Lead mule swings wide: When approaching sharp corners, the lead mule can swing wide to the outside of the corner to give the chair as much room as possible to get around the corner. This is most effective on sharp corners with few obstacles and allows the chair to get around the corner with the least amount of forward momentum.
- b. Multi-point turn: If there isn't room for a wide swing, or if obstacles require the chair to slow, a multi-point turn (alternately moving forward and then

- backing up, turning as much as possible on each leg of the turn) may be required.
- c. Pivot turn: When the corner is extremely tight or obstacles prevent any other technique, the driver can lift the front wheel off the ground and turn the chair on the two main wheels with the help of mules. In a variation of this technique, the chair can be lifted by two or more side mules, turned, and placed down facing the right direction. The pivot turn usually requires planning and discussion about exactly what needs to be done. On very tight corners, the poles can be detached, the turn made, and the poles reconnected.
- Uphill: Uphill hiking is challenging because of the effort involved but it is usually pretty straight-forward.
 - a. Uphill on a smooth trail: The driver pushes and the lead mule pulls, pulling with a towing strap or attached to the poles by a harness. The towing poles become more useful as the trail steepens and when there are other mules to help guide the front wheel around obstacles. As it gets steeper, front mules can be added as needed. Make sure to space the front mules so they don't interfere with each other or the lead mule.
 - b. Uphill on a rough trail: Again, the driver pushes, the lead mule pulls, and front mules pull as it gets very steep. Specific situations include:
 - i. When there is an obstacle such as a step or a big rock, log, or root that the chair can't straddle or roll over, the driver communicates that they are going to pop a wheelie (gently!) to lift the front wheel over the obstacle.
 - ii. When the obstacle is large, the side mules can grab the lifting points on the frame and lift and pull the main wheels over the obstacles. Don't use the forward beam to lift the chair. The forward beam can be used to tip the chair back on the main wheels (a wheelie).
- 5. **Downhill:** Downhill hiking may be less strenuous than uphill hiking but on steep and rough trails it takes lots of coordination and thought.
 - a. Downhill on a smooth trail: The driver uses the brakes to keep the chair from going too fast. If using the towing poles, the lead mul can push back against the poles to help slow the chair (taking care not to get pushed out of the way by the poles). As the trail steepens, rear mules can help hold the chair back with the straps.
 - Downhill on a rough trail: All the same techniques described for traveling on a rough uphill trail are used, except that the front mules are replaced by rear mules. The two primary differences are that
 - the speed of the chair needs to be controlled carefully with the brakes and by the rear mules and
 - ii. it is more difficult to lift the front wheel over obstacles when traveling downhill. Some lead mules prefer a towing strap to the towing poles in these conditions. In either case, the lead mule may need help from side mules to direct the front wheel over and around obstacles. When using a

strap, the lead mule should stay far enough in front and/or to the side to avoid the front wheel.

- **6. Crossing wide obstacles:** When crossing wide obstacles like water bars or stairs, square the chair to the obstacles so that both wheels roll over at the same time to prevent any chance of tipping the chair.
- 7. Sidehill: Narrow trails crossing steep side hills are the most challenging and dangerous situations for the AdvenChair. When this situation is encountered, stop and consider if it is safe to continue. If the section is short, it may be acceptable to continue even if the sidehill is steep. But if the steep sidehill is continuous for a long ways, it is best to turn around. Consider how much the chair tilts and how stable the sides of the trail where side mules will have to walk are. It is very important to move slowly and give the side mules plenty of time to adjust their position. Techniques for crossing sidehills can be combined:
 - a. The rider leans into the sidehill to help shift the center of gravity uphill. The rider's core strength is a large determinant of how steep a sidehill can be navigated.
 - b. The driver lifts up on the downside handlebar to keep the chair from tipping over. (Figure 14.)
 - c. Lift or support the chair on the downhill side: If the downhill side of the trail is stable enough and free of branches and other obstacles, have side mules ready to step to the downhill side of the trail to lift the downhill side of the chair using the lifting handles on each side (Figure 13.).
 - d. Straps pulling to the uphill side: If the uphill side of the trail is stable and free of branches and other obstacles, one or two side mules can attach straps to the side of the chair or back of the seat and pull up and to the side to keep the chair from tipping to the downhill side. (Figure 12. and Figure 14.)

Before using these techniques, make sure that the side of the trail is stable enough to hold the side mules and that they can safely walk over any branches, rocks or other obstacles without tripping or sliding down the hill.




Figure 14: Using straps and the handlebars to cross a steep sidehill.

- 8. Narrow passages: Very narrow trail sections or trails constricted by rocks, trees, or logs, which cannot be navigated by the AdvenChair, can be a dead end and may require turning around if more than a few feet long. If they are only a few feet long, and you're unlikely to encounter more, lift the rider out of the chair and carry her/him through the narrow trail section, and lay or sit him/her down in a safe location. Then get the AdvenChair through, around, or over the narrow trail section. Re-load the rider, and you're off! This technique requires enough people to move the rider safely and to get the chair through the passage without damage.
- 9. **Strap handling:** Use of the straps is pretty simple, but requires some planning and thought.
 - a. Make sure the straps are attached securely to one of the AdvenChair mounting points with a carabiner. (Figure 12.)
 - b. Holding the straps: The straps must be held securely so that they aren't dropped and the loose end doesn't trip someone.
 - i. Hold in hands: If the force on the straps is not going to be extreme, the straps can be held directly in the hands. To get better purchase on the strap, the strap can be wrapped around the mule's hand. The strap handler should be able to drop the strap to prevent the strap from sliding through the hand causing a rope burn.
 - ii. Wrap around body: Another way to hold the strap is to pass the strap around the strap handler's waist or hips, and then hold the end of the strap in the hand. The extra friction of the strap around the body makes it much easier to apply force to the strap. The strap is held much like a rock climb belayer holds a rope.

Straps can be used in many configurations and as the team gains experience, they will figure out their preferred techniques and develop the ability to improvise. A few considerations:

- Make sure the mule's footing is stable and secure to minimize slips, trips, and falls.
- Make sure that if unexpected force is put on the strap that the mule has the ability to handle that force.
- Make sure that if the mule falls or loses grip on the strap, the chair is not at risk of tipping and other members of the team are not at risk of falling.
- Many mules appreciate work gloves to protect their hands.
- 10. Rest breaks and lunch: When stopped, make sure the brakes are locked so the AdvenChair can't roll, even on flat ground. Make sure the rider is comfortable, gets a chance to stretch legs and get feet out of the footrest straps.

Finding Trails to Hike

There are many websites which describe locations and characteristics of trails. Many focus on particular geographic areas or types of travel but few provide much information about accessibility. When reading these trail descriptions, pay attention to clues about accessibility such as references to narrow bridges, steep stairs and so forth. Use web searches to find trails in your area. Some example sites include:

- AdventureGuru
- All Trails (requires a subscription for full use)
- Oregon Hiker's Guide
- Accessible Nature
- Trail Link
- American Hiking
- Access Recreation
- The Bend Bulletin Outdoors

Many of these sites let users suggest and describe trails that aren't on their sites. Let others know what great hikes you recommend!

Tell your AdvenChair stories

Contribute stories of your hikes to inspire others to get outdoors and hike! Send your stories to info@advenchair.com and we'll post them to www.advenchair.com/field-notes. Help others to Roll Boldly!

Use the **Trail Notes** section in this guide to keep notes about your hikes so that you can pass your stories on to others.

In this section, keep track of your adventures on the trail... Date: Trail: Distance: Team: Weather: Trail rating/description:

Trail Notes

Notes:

Date:	Trail:	Distance:
Team:		
Weather:		
Trail ratios/das	parintian	
Trail rating/des	scription:	
Notes:		

Date:	Trail:	Distance:
Team:		
Weather:		
Trail rating/descrip	otion:	
Notes:		

Date:	Trail:	Distance:
Team:		
Weather:		
Trail rating/descripti	on:	
Notes:		

Trail:	Distance:
ion:	

Date:	Trail:	Distance:
Team:		
Weather:		
Trail rating/descripti	ion:	
Notes:		

Trail:	Distance:
ion:	

Date:	Trail:	Distance:
Team:		
Weather:		
T	and the co	
Trail rating/des	scription:	
Notes:		

Date:	Trail:	Distance:
Team:		
Weather:		
Tue: uetices/ales	a minetia na v	
Trail rating/des	scription:	
Notes:		

Date:	Trail:	Distance:
Team:		
Weather:		
Trail rating/des	scription:	
Notes:		
140100.		

Date:	Trail:	Distance:
Team:		
Weather:		
Trail rating/de	scription:	
Notes:		
. 13100.		

Ready to Roll Checklist

- 1. Expected time frames for the hike
- 2. Expected weather
- 3. Expected trail conditions
- 4. Explanation of team member roles
- 5. We're not in a hurry. Slow down when things get rough
- 6. Communicate about trail conditions.

What should be considered an obstacle and worth talking about?

- 7. Review voice commands
- 8. Remember that shorter drivers can't see the trail. Help them out
- 9. Who is the point-of-contact if help is needed?

What is their phone number?

10. Is there cell service for a 911 call?

AdvenChair COVID-19 Protocols

Pay attention to the four Cs: Close contact, confined spaces, crowds, choices.

Every individual ultimately must make a personal decision about the level of risk he or she is comfortable with, weighing their own age and health status, life circumstances and general level of risk aversion or tolerance.

- All team members are free of COVID-19 symptoms: temperature, cough
- Maintain social distancing of at least 6 feet
- Wear a mask when near others
- Limit team size to 5 Rider, driver, 3 mules. Preferably driver is from household of rider, or in regular contact. Mules preferably from same household or in regular contact
- Clean chair between users
- Use hand sanitizer
- Avoid touching face
- Communication from a distance to mitigate proximity
- Use easy, moderate trails that do not require lifting
- Limit time in proximity to others
- Travel separately in vehicles to/from trailhead

"The wild requires that we learn the terrain, nod to all the plants and animals and birds, ford the streams and cross the ridges, and tell a good story when we get home."

~Gary Snyder

